INVISILED® ACCESSORIES

Outdoor mounting accessories for InvisiLED® Outdoor



				Fixture Type: Catalog Number: Project:
				Location:
Clear Channel		T24-WE-CH5	5 feet	Rigid, non-flexible channel for mounting to a straight, solid surface.
Mounting Clip 1		LED-TO24-C1	10 pcs	For installation on non-flat surfaces where there is no edge contact. 2 clips per ft are recommended for straight runs.
Mounting Clip 2		LED-TO24-C2	10 pcs	For installation on non-flat surfaces, allows for contact on one edge. 2 clips per ft are recommended for straight runs.
Mounting Clip 3	101	T24-WE-C3	10 pcs	For installation on non-flat surfaces, allows for contact on both edges. 2 clips per ft are recommended for straight runs.

INVISILED® ACCESSORIES



both edges. 2 clips per ft are recommended for straight runs.

Outdoor mounting accessories for InvisiLED® Pro Outdoor and InvisiLED® Palette Outdoor

Mounting Clip 3

			Fixture Type:
			Catalog Number:
			Project:
			Location:
Clear Channel	LED-TO24-CH5	5 feet	Rigid, non-flexible channel for mounting to a straight, solid surface.
Mounting Clip 1	LED-TO24-C1	10 pcs	For installation on non-flat surfaces where there is no edge contact. 2 clips per ft are recommended for straight runs.
Mounting Clip 2	LED-TO24-C2	10 pcs	For installation on non-flat surfaces, allows for contact on one edge. 2 clips per ft are recommended for straight runs.
Mounting Clip 2	LED-TO24-C2	10 ncs	For installation on non-flat surfaces, allows for contact on

LED-TO24-C3